



**OXYSYNC™**  
**Quick Start Guide**

---

**SYSTEM STARTUP**

1. Locate the control screen and navigate to the **Zone control panel** tab.
2. Press the **Off** button.
3. Confirm the indicator changes to **On**.

When the indicator is green, the system is operating according to its programmed schedule.

---

**USING OXYBURST**

1. While on the Zone control panel tab, Press the **Oxyburst** button for the desired zone.
  2. The system will begin an immediate oxygen cycle.
  3. After the cycle is completed, the system will automatically return to the normal schedule.
-

## NORMAL OPERATION

- The system operates daily according to the programmed schedule.
  - No daily user input is required.
  - When leaving for an extended period, turn all of the zones to **Off** to put the system into standby mode.
- 

## TROUBLESHOOTING BASICS

- Check the Control screen under the **Zone control panel**. Confirm the zone is showing “**On**” for the desire zone.
- If the units are not running, double check the system is not in a programmed off cycle. This can be found under the **Zone control panel**. Press the three dots to the right under the Action column. Now press the **View Timer** option.
- Press the **Oxyburst** mode button to double check the units turn on and there is not a power issue (Tripped breaker, unplugged unit, ect.)
- Make sure to close doors and windows in the oxygenated zone.

If assistance is needed, contact your authorized service provider.

---